

Neo-Pure® Contaminant Reduction* Includes:

- Atrazine
- Chlorine, Taste & Odor
- Mercury @ pH 8.5
- Asbestos
- Cysts
- Particulate Class I Particle Size: ≥ 0.5 to $< 1\mu$ m
- Benzene
- Lead
- P-Dichlorobenzene
- Carbofuran
- Mercury @ pH 6.5

Application Guidelines - Water Supply Parameters

Service Flow	0.5 gpm (1.9 lpm)
Water Pressure	20-120 psi (138-827 kPa)
Water Temperature	33°F -100°F (0.6°C-37.8°C)
Rated Service Capacity	300 gallons (1,136 liters)

Systems must be installed and operated in accordance with manufacturer's recommended procedures and guidelines. Failure to do so may void warranty.

⚠ **WARNING:** Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used on disinfected waters that may contain filterable cysts.

CAUTION: To reduce the risk associated with property damage due to water leakage:

- Read and follow Use Instructions before installation and use of this system.
- Installation and use **MUST** comply with all state and local plumbing codes.
- Protect from freezing, remove filter cartridge when temperatures are expected to drop below 33° F (0.6° C).
- **Do not install on hot water supply lines.** The maximum operating water temperature of this filter system is 100° F (38° C).
- Do not install if water pressure exceeds 120 psi (827 kPa). If your water pressure exceeds 80 psi (552kPa), you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.
- Do not install where water hammer conditions may occur. If water hammer conditions exist you must install a water hammer arrester. Contact a plumbing professional if you are uncertain how to check for this condition.
- Where a backflow prevention device is installed on a water system, a device for controlling pressure due to thermal expansion must be installed.
- The disposable filter cartridge **MUST** be replaced every 6 months, at the rated capacity or if a noticeable reduction in flow rate occurs.
- Entire system (excluding disposable cartridges) is warranted for a period of one year. Disposable cartridges are warranted for defects in material and workmanship only. Service life of disposable filter cartridges varies with local water conditions and is thus not warranted.

*Based on manufacturer's internal testing.



Tested and certified by NSF International against NSF/ANSI Standard 42 for material safety and structural integrity only.

All company names are registered trademarks of their respective holders. Made in Korea. ©2017 NeoLogic Solutions

NEO-PURE®

Filtration Products

Refrigerator Filter Reduces Top Contaminants Including Lead!*

NP-LT600P Compatibility:

LG®

- LT6009
- 5231JA2006A-S

Sears® & Kenmore®

- 9990
- 46-9990




Procedure For Filter Cartridge Installation And Replacement.




Replace your filter when the refrigerator water filter indicator light is on, or when your water dispenser or ice maker performance decrease noticeably.

- 1 If you are replacing the cartridge, first twist the handle of the cartridge counterclockwise.




1




2

- 2 The cartridge will eject slightly with a clicking sound and pull out the cartridge. Some water may remain in the old cartridge, so hold the cartridge with the handle down to avoid spillage.




1




2

- 3 Insert the new cartridge with the handle in the vertical position, push into the housing until it stops. Twist the handle of the filter cartridge clockwise about 1/4 turn until you feel it stop.



1



2

- 4 Flush the refrigerator water system after replacing the water filter cartridge. Flush 2.5 gallons through filter before use (flush about 5 minutes). After replacing the cartridge, reset the water filter status display and indicator light by pressing and holding the reset button for 3 seconds.